

# Congratulations!

on the arrival of your Custom Mini Monitors from ListenHear™.

Your Custom Mini Monitors deliver rich sound quality and superior long wear comfort, making them ideal for MP3 players, including iPod®, and other audio equipment. The custom soft-gel earpieces will stay in place while jogging or exercising. The acoustic design makes lower volumes more satisfying to protect hearing; however, they can deliver a quantity of sound that deserves respect. Please use them carefully. The sound isolating feature of the Custom Mini Monitors make them ideal for flying and other noisy environments.

## Use

Identify the left and right earpiece by the colored dot on each: the blue dot signifies the left ear, and the red dot signifies the right ear. Using your left hand, insert the left earpiece while using your right hand to gently pull the outer ear up. Then, slowly rock and/or turn the earpiece until it fits securely into place. Repeat the procedure for the right earpiece.

## Care

Carefully wipe the earpieces with a clean, soft cloth after each use. The earpieces may be removed from the earphones for periodic cleaning in mild soap and water. Do not replace the earpieces until thoroughly dry. Remember – Your earpieces are custom fit to your ears only. You should not let others attempt to use them.

### Specs:

Sensitivity (1000 Hz): 110 dB @ 1 mW

Impedance (1000 Hz): 16 ohms

Driver: Single dynamic

Cables: 1/8" (3.5mm) mini connector. 45" length.

Warranty: 90 days

**Please direct your comments, suggestions or questions to us at [ListenHearStore.com](http://ListenHearStore.com) or 1.800.262.8611.**

© 2007 Starkey Labs, Inc.

ListenHear is a trademark of Starkey Laboratories, Inc.

INST0038-00-EE-XX 83585-007 7/07

 ListenHear™